



DETECTABUSE® GRAVITY SERIES GV-65 / GV-65C METHOD FOR THE ANALYSIS OF BARBITURATES IN URINE BY GC/MS

Please see Notes and Supplemental Information before proceeding

MAY 2010

SAMPLE PREPARATION

- 1. Add 1.0 -2.0 mL of sample to a 16 x 100 mm disposable glass culture tube.
2. Add 100 ng of Phenobarbital-D5 per mL of sample
3. Add 3.0 mL of 0.25M Phosphate Buffer, pH 9.1. Vortex mix.

COLUMN CONDITIONING - ALL LIQUIDS FLOW BY GRAVITY

Column Conditioning

- 1. Wash column with 1.0 mL of Methanol.
1. Wash column with 1.0 mL of deionized H2O
3. Proceed to Sample Extraction within 20 min. of column conditioning.

SAMPLE EXTRACTION

- 1. Pour samples onto preconditioned column.
2. Wash column with 3.0 mL of deionized water.
3. Wash with 1.0 mL of DI Water:Methanol (60:40).
4. Dry the columns by applying vacuum adjusted to at least 7" Hg for 5 minutes.

SAMPLE ELUTION

- 1. Place the column mounting plate on the elution rack loaded with corresponding labeled 12 x 75 mm or 16 x 100 mm tubes.
2. Add 1.0 mL of n-Butylchloride with 4% Triethylamine (TEA).
3. Dry under N2 or argon at less than 50°C.

ON-COLUMN DERIVATIZATION

- 1. To each dried extract add 50 µL ethyl acetate and 50 µL Methylating reagent; such as 0.2M Trimethylphenyl Ammonium Hydroxide (TMPAH) in Methanol
2. Transfer to vials with inserts and cap.

MSD SIM PROGRAM Drug

Ions Monitored

Table with 2 columns: Drug and Ions Monitored. Lists various barbiturates and their corresponding m/z values.

NOTES:

- 1. SAMPLES AND WASHES - Allow all samples and washes to gravity flow completely through the resin bed before adding the next liquid.
2. INTERNAL STANDARDS - When preparing the Internal Standard the quantity added per mL of sample should approximate the cutoff value of the compound(s) being tested for.
3. TURBID SAMPLES may need to be centrifuged
4. RINSE SOLVENTS should be delivered to the top part of the column to better remove the aqueous.
5. ELUTION SOLVENTS with the TEA should be made fresh daily.
6. POLAR SOLVENTS used (e.g. acetonitrile and ethyl acetate) may absorb moisture.
7. AIR TRAPPED within the column bed or frits may prevent the liquids from eluting freely by gravity flow.
8. IDEAL FRAGMENTS should be determined by full scans of neat, derivatized standards.
9. RECOMMENDED CAPILLARY COLUMNS for adequate partitioning of all barbiturates would be 100% polydimethylsiloxane or 95% polydimethylsiloxane:5% phenyl

This method is a preliminary procedure for investigational use only. Although it has performed well in our laboratory, your laboratory must validate it before it is used to report patient values. We would appreciate your comments on its performance and welcome your suggestions for improvements or enhancements.